Copy a video off an AJA KiPro

The first step is safely Ejecting the hard drive from the AJA KiPro, and mounting it on the computer.

Make sure the AJA KiPro recording unit is no longer recording by pressing 'Stop.' Turn the AJA KiPro off by holding down the power button. Hold down the power button until the KiPro turns off.

With the KiPro off, hold the Eject button, and gently pull the cartridge out.



Take the cartridge to DVR1 or DVR2 in 4F Control. Plug the a Firewire 800 cable next to the monitor into the back of the cartridge.



Now we will copy the video from the KiPro hard drive.



Find the latest recording. The recordings are in numerical order. 9.00 AJA 4 1 22 = 111 111 O 4-Q Clip1ATK79.mov ■ Clip1ATK80.mov Macintosh HD Clip1ATK81.mov tempstorage Clip1ATK82.mov FIREFLY Clip1ATK83.mov Clip1ATK84.mov SHARED Clip1ATK85.mov fileserver.... * Clip1ATK86.mov Clip1ATK87.mov @ All... Clip1ATK88.mov Clip1ATK89.mov 💹 Desktop Clip1ATK90.mov inneyiw Clip1ATK91.mov 🐴 Applicatio Clip1ATK92.mov Clip1ATK93.mov SEARCH FOR Clip1ATK94.mov Today Clip1ATK95.mov Yesterday Drag the last recording to the local hard drive of your machine. This will take some time to copy. tempstorage After the copy has completed, eject the KiPro hard drive by selecting the hard File Edit View Wind drive icon and selecting 'File > Eject' or dragging it to the Eject icon in the dock. New Finder Window ЖN New Folder **企業N** New Smart Folder NWC New Burn Folder Open жo Open With Print Close Window ₩W ЖI Get Info Compress ₩D Duplicate Make Alias ЖL Quick Look "001" **Ж**Υ Show Original 36R Add to Sidebar **%T X** (X) Move to Trash Eject "001" ЖE Burn "001" to Disc... Unplug the AJA KiPro harddrive from the system and return it to the KiPro recording device.