

Sony A1U - Menu Output to Projector

Connect the proprietary composite video cable to the A1U. This should come with the camera that you checkout.




Plug into the AUX input of the Studio A/V rack



Press AUX as the source and choose Composite as the Aux Input



Press "MENU"
On the touch screen fold out LCD on the camera



Press "MENU" again



Press "Standard Set"
Press OK



Press "Disp Output"
Press OK



Press V?OUT / PANEL This will display the on screen menus ON the camera LCD screen and the video output so that one can monitor the image WITH menu items on projector screen.

