

Using the number keypad

On my Dell notebook computer, how can I use the number keypad?

Turn on **Num Lk**, and then to use the number keypad, hold down **Fn** while pressing the keys on the number keypad.

If you'd like to enable the keyboard to use the number keypad just by turning on **Num Lk**, follow these instructions:

1. Restart your computer
2. While it is booting up, press **F2** to go into the BIOS screen
3. Go to **POST Behavior** and then **Keypad (Embedded)**
4. Turn on **By Num Lk** (if you're not sure how to do this, instructions on how to move around in BIOS are at the bottom of your screen)
5. Hit **Esc**, then select **Save and Exit**, and allow your computer to finish starting up
6. Now you can just press **Num Lk** whenever you want to use the number keypad