Classroom Technology Rounds Items to Check

INTRODUCTION

This page addresses the instructions for checking if the Classroom AV technology is in a ready state classes. These steps include images of what the system SHOULD like when visual inspection is occurring. You will fill out the Troubleshooting Checklist Matrix for Classroom Technology Problems. Item Image COMP **UTER TURN** Power Button ED ON? Look for a small bright white light on COMM859141 the right S ide White Power Light of the com pute r.

MOUS E LIGHT ON?

Look for a red LED on the botto m of the mouse








Bad: No Light

LCD MONI TOR LIGHT ON?

Look for an Amber (Stand by) or Blue (On) LED on the botto m rig ht of the Mon itor.









Bad: No Light

TOUC HPAN EL ON?

Touch the Touch Panel with you finger to Wa ke it up.



Good: Touchpanel ready at Home Screen



Bad: Projector is off, but touchpanel thinks the system is still on from yesterday.

Conf irm that it is on the Hom е Scre en and read у for а teac her to start clas s.




ROO M SCHE DULE R WOR KING & UP TO DATE?

Wake room sched uler (s) outsid e the room by touchi ng or wavin g your hand front of it.

Conf irm roo m sche dule r is on toda y's date and sees upc omi ng eve nts (ava ilabl е for the next Χ

hour s)..



MICR OPHO NES & BATT ERIES READ Y?

In rooms with mics, please confir m that the microp hones are in the la bele d micr oph one dra

New
Batt
erie
s
hav
e a
blac
k
cap
over
the
term
inals.

wer.

Stock new 9v Batteri es in drawe r. Provid e 1 per mic.




Remo ve uncap ped /used batteri es and return to helpde sk for testing /recycl ing.

LAPT OP CABL ES READ Y?

Look at the audio, HDMI, and VGA cabl es on the teac hing cons ole.

Conf irm that the 3 cabl es are pres ent and are in goo d sha pe.



- B e n t P ins
 L o o s e C o n n e ct o rs B r o k e n C a bl es

ALAR M PANE LS ARME D?

All alarms in hallwa ys should be armed at all times.

Look for a red "Arme d" LED on the left of the panel.







Bad: Not Armed

ARE HALL WAY TVs ON?

Verify the hallwa y TVs are on, runnin g in Full Scree n mode, and proper ly changi ng slides every few secon ds.

