

Angenieux 15-150 Cine Zoom Lens

STORAGE / TRANSPORTATION INSTRUCTIONS

IRIS RING / FOCUS RING

- Set the Iris ring to wide open on all lenses (lowest F-stop number), always. In the wide-open position, the blades are folded and protected by the iris plates and less susceptible to damage.
- set focus to infinity

ZOOM RING

- Set Zoom to most telephoto focal length (150mm)

*This lens uses springs in the zoom section. The 150mm Focal distance is where the springs are least extended *

